

Steps for working as an undergraduate in the Weber lab.

1) Library training: An important part of research is keeping up with the current discoveries. When you start working on a project you will be expected to work to become an expert in that area. When you go to present at conferences you will need an in-depth knowledge of the material. As a researcher and scientist, I expect that you will regularly read scientific papers to keep up on discoveries published in the field. The BYU science librarian will train you on how to conduct literature searches for your research and how to access the online resources available at BYU. Schedule an appointment with Dr. Greg Nelson at <http://guides.lib.byu.edu/mmbio> and request instruction on how to do a literature search.

I have completed the library literature research component: Signed _____ Dr. Nelson _____ Date _____

2) Immunology background: Immunology is a fascinating field with so many interesting aspects to learn. It will be good to sign up for the Infection and Immunity (MMBIO 261) and Immunology (MMBIO 463) courses in the future if you have not already taken them. In the meantime, there are some good immunology videos online that will introduce you to some terms and concepts you will see in the papers we read. Please go to Khan Academy (<https://www.khanacademy.org/>) and do a search on the term "Immunology". This will bring up several videos you can watch to get up to speed on the basics.

I have watched the online Immunology video's: Signed _____ Dr. Weber _____ Date _____

3) Lab meeting: If you want to be able to successfully do scientific research it requires dedication in applying yourself to learn new material and finish projects. If you can attend lab meeting each week you will be able to hear lab members present on their work and papers related to their project. You will be asked to present a short summary of your research progress at the end of the semester. You will have ~15 minutes to present what you have done over the semester (project background, hypothesis tested, and experimental results and conclusions). You need to be prepared to answer questions about your work and the paper. If you are unable to attend lab meeting, please let me know and we can work it out.

I attended lab meeting my first semester in the lab: Signed _____ Dr. Weber _____ Date _____

4) Student Flow Cytometer Training: Our lab frequently uses the flow cytometers in the Research Instrument Core (RIC) to generate data and test hypotheses. Please schedule with Dr. Sandra Hope in MMBIO to do the 2-hour training so you can operate the student flow cytometer ([sandra hope@byu.edu](mailto:sandrahope@byu.edu); 3134 LSB). I teach a 2-credit flow cytometry course in the Fall (MMBIO 522) that you can consider taking so you understand in depth how to design, run, and analyze flow cytometry experiments.

I completed the Student Flow Cytometer Training: Signed _____ Dr. Weber _____ Date _____

5A) Lab safety training: Before you can work in a lab at BYU you must complete safety training. Proper safety training helps prevent injuries or accidents. Go to <https://risk.byu.edu/ehs/shp> and then click on the "laboratory safety" module to complete the online instruction and short quizzes. The safety training described is valid for 1 year. To work in the lab you will need to renew your safety training each year.

I completed the online safety training: Signed _____ Dr. Weber _____ Date _____

5B) Lab specific safety training: In the lab we occasionally use the bacteria *Listeria monocytogenes* to infect mice. This is a Biosafety level 2 organism, and we have a Weber lab Biosafety manual in this packet. Please read over it and sign the last page when you are done.

I read the biosafety manual and will follow the safety rules: Signed _____ Dr. Weber _____ Date _____

5C) Mouse Safety Training: To have access to the vivarium and work with mice, you need to complete the following CITI and Y-train online modules, be added to the lab IACUC protocol, do in person training with a lab member, and get independent access to the vivarium. Here are the steps to do this:

1. Go to citiprogram.org and click "Login". Next do "Login through my Institution" and click "Brigham Young University – Provo UT". Then "Sign in to BYU account" and enter BYU Net ID and Password
2. Click "I don't have a CITI Program account and I need to create one" (if you already have a CITI account, choose the other option) and then click "Create A New CITI Program Account".
3. You should see the following: CITI Program: Collaborative Institutional Training...To add a course click "Add a course" Brigham Young University-Provo, UT courses

4. Scroll down to choose your curriculum, you should choose and complete:

- 1) Undergrad/Grad Students - Working with the IACUC
- 2) Undergrad/Grad students - Post-Procedure Care of Mice and Rats in Research
- 3) Undergrad/Grad students – Working with Mice in Research Settings

5. You also need to complete an online training module on Y train. Search for "ABSL Training" and enroll and complete the 7-module training. Print up the completed form.

6. Once you have completed the CITI and Y Train online modules, go to byu.imedris.net and login with your NET ID and then logout (this gets you in the directory). Send an email with your BYU ID number to Dr. Weber and request that he submit an IACUC personal amendment for you to work with the mice.

7. When Dr. Weber lets you know that the IACUC has approved adding you to the IACUC protocol, you will want to ask the graduate student you are working with to give you the hands-on mouse facility training. They can then help you request the vivarium manager give you card access to the vivarium.

6) Laboratory Technique Training: Once you have your safety and mouse training completed you start working in the lab. You will want to ask others in the lab to help you learn basic research techniques (e.g., how to make media, pour DNA gels, run a PCR reaction, perform an ELISA, do cell culture, freeze down cells and bring them back up, accurately complete cell and viability counts and other general techniques). If you work hard and are careful and reliable, you can become more and more independent in the lab. This can lead to a number of things including giving presentations at a major science meetings.

7) Project mastery and consistent effort: Participation in mentored research can help improve your chances to obtain positions in graduate or professional schools, but only if you are prepared to put in the effort. If you put in the time and effort to master the material for your project (evaluating science and performing laboratory work) you will be able to be able to present your work at National and International conferences. It benefits you and my lab if you become an excellent researcher, take advantage of this opportunity to master your project!

Picking a Journal Club Paper

Overview: Participating in a regular Journal club provides a way to keep abreast of new developments in Immunology and to learn how to read scientific papers and evaluate them. Learning how to present a journal club paper is an important skill for now and in the future.

Tips on choosing a paper: The foundation of an outstanding journal club presentation rests on the choice of an interesting and well-written paper for discussion. Pick a paper that you are interested in, that has been published in the past year, and it should usually be in one of the top journals for Immunology (see list below). While there are no guarantee that the papers in these journals are great, because of the review process that they go through to get accepted in these journals the odds are better.

Good Immunology Research Journals

Nature, Science, Cell, Nature Immunology, Immunity, Cell Host and Microbe, PNAS, PLOS Pathogens
Journal of Immunology, Molecular Immunology

Review Journals - included as a reference, we will be presenting articles from research journals.

Annual Reviews of Immunology
Nature Reviews Immunology

Keeping up on reading papers: I would recommend that you sign up to be emailed the electronic table of contents (eTOCs) for Science and Nature (register on their websites) and any other journals relevant to your work. This will help you keep up with the best new science.

Journal Impact Factors: While journal impact factors are never an indicator of how good a paper in that journal will be, if you want to get a feel for how a journal of interest is ranked here: <http://admin-apps.webofknowledge.com/JCR/JCR?PointOfEntry=Home&SID=1E3@clKH8mjebkLhi18>. You can search by scientific categories or search by the specific journal name.

How to read a scientific paper: Please review the basics of how to read a scientific paper at: www.sciencebuddies.org/science-fair-projects/top_science-fair_how_to_read_a_scientific_paper.shtml

Weber lab Biosafety 2 Manual (10/22/14)

One of the projects in the Weber lab involves the use of the Biosafety level 2 (BSL-2) pathogen *Listeria monocytogenes*. Everyone in the lab needs to understand the safety precautions necessary to work with *Listeria monocytogenes* and be trained on proper BSL-2 technique. Each lab member must read and then discuss this manual with Dr. Weber and get his signature as a prerequisite for working in the laboratory.

All of the BSL-2 work must be done in room 3126A LSB or the mouse room 1012B LSB. All of the BSL-2 safety policies are below, but I want to emphasize that when working with *Listeria monocytogenes* gloves and labcoats must be worn and your hands washed with soap after working with *Listeria monocytogenes* and before leaving the room. All BSL-2 samples must be processed in the hood. After use, the hood must be cleaned with a 1:10 dilution of Lysol I.C. quaternary disinfectant cleaner and 95% ethanol. Any *Listeria monocytogenes* waste samples must be placed in bleach (1:10 dilution) before disposal in the biohazard containers. Flow cytometry samples need to be fixed with 2% paraformaldehyde before analysis and after analysis the tubes must be bleached and disposed of in the biohazard containers.

This manual has two parts, the 1st contains the biosafety level 2 standard practices our lab will follow (pages 6-9) and the 2nd has the Pathogen Safety Data Sheet for *Listeria monocytogenes* (pages 10-14).

Restrictions: The groups with the highest risk for *Listeria monocytogenes* infection and subsequent health risks are pregnant women, the elderly, and immune-compromised individuals. Anyone student or employee in any of these categories will not work on this *Listeria monocytogenes* project as a precaution.

I have read this biosafety manual and agree to follow the biosafety level 2 rules described.

Lab member

Date

Dr. Weber

Date

Biosafety Level 2 lab practices

Biosafety Level 2 builds upon those already used in BSL-1. BSL-2 is suitable for work involving agents that pose moderate hazards to personnel and the environment. It differs from BSL-1 in that 1) laboratory personnel have specific training in handling pathogenic agents and are supervised by scientists competent in handling infectious agents and associated procedures; 2) access to the laboratory is restricted when work is being conducted; and 3) all procedures in which infectious aerosols or splashes may be created are conducted in BSCs or other physical containment equipment.

The following standard & special practices, safety equipment, and facility requirements apply to BSL-2:

A. Standard Microbiological Practices

1. The laboratory supervisor must enforce the institutional policies that control access to the laboratory.
2. Persons must wash their hands after working with potentially hazardous materials and before leaving the laboratory.
3. Eating, drinking, smoking, handling contact lenses, applying cosmetics, and storing food for human consumption is not be permitted in laboratory areas. Food must be stored outside the laboratory area in cabinets or refrigerators designated and used for this purpose. Food cannot be consumed in the laboratory.
4. Mouth pipetting is prohibited; mechanical pipetting devices must be used.
5. Policies for the safe handling of sharps, such as needles, scalpels, pipettes, and broken glassware must be developed and implemented. Whenever practical, laboratory supervisors should adopt improved engineering and work practice controls that reduce risk of sharps injuries.

Precautions, including those listed below, must always be taken with sharp items. These include:

- a. Careful management of needles and other sharps are of primary importance. Needles must not be bent, sheared, broken, recapped, removed from disposable syringes, or otherwise manipulated by hand before disposal.
 - b. Used disposable needles and syringes must be carefully placed in conveniently located puncture-resistant containers used for sharps disposal.
 - c. Non-disposable sharps must be placed in a hard walled container for transport to a processing area for decontamination, preferably by autoclaving.
 - d. Broken glassware must not be handled directly. Instead, it must be removed using a brush and dustpan, tongs, or forceps. Plasticware should be substituted for glassware whenever possible.
6. Perform all procedures to minimize the creation of splashes and/or aerosols.
 7. Decontaminate work surfaces after completion of work and after any spill or splash of potentially infectious material with appropriate disinfectant.
 8. Decontaminate all cultures, stocks, and other potentially infectious materials before disposal using an effective method. Depending on where the decontamination will be performed, the following methods should be used prior to transport:
 - a. Materials to be decontaminated outside of the immediate laboratory must be placed in a durable, leak proof container and secured for transport.
 - b. Materials to be removed from the facility for decontamination must be packed in accordance with applicable local, state, and federal regulations.
 9. A sign incorporating the universal biohazard symbol must be posted at the entrance to the laboratory when infectious agents are present. Posted information must include: the laboratory's biosafety level, the supervisor's name (or other responsible personnel), telephone number, and required procedures for entering and exiting the laboratory. Agent information should be posted in accordance with the institutional policy.

10. An effective integrated pest management program is required.
11. The laboratory supervisor must ensure that laboratory personnel receive appropriate training regarding their duties, the necessary precautions to prevent exposures, and exposure evaluation procedures. Personnel must receive annual updates or additional training when procedural or policy changes occur. Personal health status may impact an individual's susceptibility to infection, ability to receive immunizations or prophylactic interventions. Therefore, all laboratory personnel and particularly women of child-bearing age should be provided with information regarding immune competence and conditions that may predispose them to infection. Individuals having these conditions should be encouraged to self-identify to the institution's healthcare provider for appropriate counseling and guidance.

B. Special Practices

1. All persons entering the laboratory must be advised of the potential hazards and meet specific entry/exit requirements. Laboratory personnel must be provided medical surveillance and offered appropriate immunizations for agents handled or potentially present in the laboratory. When appropriate, a baseline serum sample should be stored.
2. A laboratory-specific biosafety manual must be prepared and adopted as policy. The biosafety manual must be available and accessible. The laboratory supervisor must ensure that laboratory personnel demonstrate proficiency in standard and special microbiological practices before working with BSL-2 agents. Potentially infectious materials must be placed in a durable, leak proof container during collection, handling, processing, storage, or transport within a facility.
3. Laboratory equipment should be routinely decontaminated, as well as, after spills, splashes, or other potential contamination.
 - a. Spills involving infectious materials must be contained, decontaminated, and cleaned up by staff properly trained and equipped to work with infectious material.
 - b. Equipment must be decontaminated before repair, maintenance, or removal from the laboratory.
4. Incidents that may result in exposure to infectious materials must be immediately evaluated and treated according to procedures described in the laboratory biosafety safety manual. All such incidents must be reported to the laboratory supervisor. Medical evaluation, surveillance, and treatment should be provided and appropriate records maintained.
5. Animals and plants not associated with the work being performed must not be permitted in the laboratory.
6. All procedures involving the manipulation of infectious materials that may generate an aerosol should be conducted within a BSC or other physical containment devices.

C. Safety Equipment (Primary Barriers and Personal Protective Equipment)

1. Properly maintained BSCs (preferably Class II), other appropriate personal protective equipment, or other physical containment devices must be used whenever:
 - a. Procedures with a potential for creating infectious aerosols or splashes are conducted. These may include pipetting, centrifuging, grinding, blending, shaking, mixing, sonicating, opening containers of infectious materials, inoculating animals intranasally, and harvesting infected tissues from animals or eggs.
 - b. High concentrations or large volumes of infectious agents are used. Such materials may be centrifuged in the open laboratory using sealed rotor heads or centrifuge safety cups.

2. Protective laboratory coats, gowns, smocks, or uniforms designated for laboratory use must be worn while working with hazardous materials. Remove protective clothing before leaving for non-laboratory areas (e.g., cafeteria, library, administrative offices). Dispose of protective clothing appropriately, or deposit it for laundering by the institution. It is recommended that laboratory clothing not be taken home.
3. Eye and face protection (goggles, mask, face shield or other splatter guard) is used for anticipated splashes or sprays of infectious or other hazardous materials when the microorganisms must be handled outside the BSC or containment device. Eye and face protection must be disposed of with other contaminated laboratory waste or decontaminated before reuse. Persons who wear contact lenses in laboratories should also wear eye protection.
4. Gloves must be worn to protect hands from exposure to hazardous materials. Glove selection should be based on an appropriate risk assessment. Alternatives to latex gloves should be available. Gloves must not be worn outside the laboratory. In addition, BSL-2 laboratory workers should:
 - a. Change gloves when contaminated, integrity has been compromised, or when otherwise necessary. Wear two pairs of gloves when appropriate.
 - b. Remove gloves and wash hands when work with hazardous materials has been completed and before leaving the laboratory.
 - c. Do not wash or reuse disposable gloves. Dispose of used gloves with other contaminated laboratory waste. Hand washing protocols must be rigorously followed.
5. Eye, face and respiratory protection should be used in rooms containing infected animals as determined by the risk assessment.

D. Laboratory Facilities (Secondary Barriers)

1. Laboratory doors should be self-closing and have locks in accordance with the institutional policies.
2. Laboratories must have a sink for hand washing. The sink may be manually, hands-free, or automatically operated. It should be located near the exit door.
3. The laboratory should be designed so that it can be easily cleaned and decontaminated. Carpets and rugs in laboratories are not permitted.
4. Laboratory furniture must be capable of supporting anticipated loads and uses. Spaces between benches, cabinets, and equipment should be accessible for cleaning.
 - a. Bench tops must be impervious to water and resistant to heat, organic solvents, acids, alkalis, and other chemicals.
 - b. Chairs used in laboratory work must be covered with a non-porous material that can be easily cleaned and decontaminated with appropriate disinfectant.
5. Laboratory windows that open to the exterior are not recommended. However, if a laboratory does have windows that open to the exterior, they must be fitted with screens.
6. BSCs must be installed so that fluctuations of the room air supply and exhaust do not interfere with proper operations. BSCs should be located away from doors, windows that can be opened, heavily traveled laboratory areas, and other possible airflow disruptions.
7. Vacuum lines should be protected with High Efficiency Particulate Air (HEPA) filters or their equivalent. Filters must be replaced as needed. Liquid disinfectant traps may be required.
8. An eyewash station must be readily available.

9. There are no specific requirements on ventilation systems. However, planning of new facilities should consider mechanical ventilation systems that provide an inward flow of air without recirculation to spaces outside of the laboratory.

10. HEPA filtered exhaust air from a Class II BSC can be safely re-circulated back into the laboratory environment if the cabinet is tested and certified at least annually and operated according to manufacturer's recommendations. BSCs can also be connected to the laboratory exhaust system by either a thimble (canopy) connection or a direct (hard) connection. Provisions to assure proper safety cabinet performance and air system operation must be verified.

11. A method for decontaminating all laboratory wastes should be available in the facility (e.g., autoclave, chemical disinfection, incineration, or other validated decontamination).

PATHOGEN SAFETY DATA SHEET - INFECTIOUS SUBSTANCES

SECTION I - INFECTIOUS AGENT

NAME: *Listeria monocytogenes*.

SYNONYM: Listeria, listeriosis, listeriasis, listerellosis, and circling disease (in animals) ^(1,13).

CHARACTERISTICS: *Listeria monocytogenes* is a facultatively anaerobic, gram-positive, rod-shaped coccobacillus, typically measuring 0.5 to 2µm long and 0.5µm in diameter ^(1,3,4,9). *L. monocytogenes* has the ability to grow at low temperature, a range of pH values (between 4.3 and 9.6), and can reproduce at temperatures between 1 and 45°C ^(1,3). *L. monocytogenes* is divided into 11 serovars; however, most human and animal cases are caused by serovars 4b, 1/2b, and 1/2a ^(1,3).

SECTION II - HAZARD IDENTIFICATION

PATHOGENICITY/TOXICITY: *L. monocytogenes* was first described as a human pathogen in the 1920s^(1,5). Although relatively rare, human listeriosis is often severe and mortality rates can approach 50%^(1,3). Certain factors predispose individuals to infection with *L. monocytogenes*, such as neonates, pregnancy, leukemia, Hodgkin's disease, diabetes mellitus, alcoholism or cirrhosis and immunosuppressive or cytostatic therapy⁽¹⁰⁾. Most commonly, listeria causes a mild febrile illness however, several types of listeriosis disease manifestations are recognised; for instance, listeriosis in pregnancy, listeriosis of the central nervous system (CNS), febrile gastroenteritis, glandular listeriosis, local listeriosis, typhoid listeriosis, and atypical listeriosis⁽¹⁰⁾.

Listeriosis in pregnancy: Occurs mostly during the third trimester, and is characterised by a "flu like" illness with symptoms such as fever, chills, malaise, arthralgia, back pain, and diarrhoea^(3,6,10,12). In many cases the infection is subclinical or inapparent; however, intrauterine infection of the foetus can lead to foetal death, spontaneous abortion, premature delivery, or the birth of a foetus that dies shortly after birth^(5,6,10). Surviving newborns with listeriosis are often classified as "early onset" or "late onset". Early onset neonatal listeriosis due to transplacental infection often presents as pneumonia and/or sepsis^(9,12). Severe disease can result in widespread granulomas (granulomatosis infantisepticum)^(9,12). Late onset neonatal listeriosis is said to occur from infection during birth, with neonates showing symptoms of meningitis one to several weeks after birth^(3,9). In both early and late onset neonatal listeriosis, the mortality rate ranges from 20 to 30%⁽⁹⁾.

Listeriosis of the CNS: Meningitis is the most frequently recognized listerial infection⁽⁶⁾. Common symptoms of listeriosis of the CNS include high fever, nuchal rigidity, tremor and/or ataxia, and seizures ⁽⁶⁾. The most common form of non-meningitic form of CNS listeriosis is encephalitis involving the brainstem (rhombencephalitis) ⁽⁶⁾.

Febrile gastroenteritis: A non-invasive form of listeriosis that manifests as symptoms typical of gastroenteritis, for example, fever, diarrhoea, and vomiting^(6,9,10).

Glandular listeriosis: Resembles infectious mononucleosis with swelling of the salivary glands and nuchal lymph nodes⁽¹⁰⁾.

Local listeriosis: Can manifest as papules and pustules on the hands and arms following direct contact with infectious material, and can be accompanied by constitutional symptoms (fever, myalgia, and/or headache)⁽¹³⁾.

Typhoid listeriosis: Characterised by high fever and is particularly frequent in immunocompromised individuals⁽¹⁰⁾.

Atypical listeriosis: Rare cases of have been described with symptoms such as endocarditis, purulent (mononuclear) pleural exudates, pneumonia, urethritis, and abscesses⁽¹⁰⁾.

EPIDEMIOLOGY: Listeriosis occurs worldwide, but is seen mostly in industrialised countries^(3,4). Although *L. monocytogenes* was described as a human pathogen in the 1920s (mistakenly thought to be the cause of infectious mononucleosis), the first documented outbreak of food-borne listeriosis was in 1979 in 23 patients in a Boston hospital^(3,5). The first confirmed outbreak in Canada, and first definitive link of listeriosis cases to food, was in 1981 in the Maritime Provinces and was due to consumption of contaminated cabbage in coleslaw⁽⁵⁾. Further outbreaks occurred during subsequent years and were often associated with a particular food type, from vegetable products in the early 1980s, to dairy products in the mid 1980s and early 1990s, to ready-to-eat meat and poultry products in the late 1990s to early 2000s^(2,5). Indeed, ready-to-eat meat and poultry products were responsible for a multi-state outbreak in the United States in 1999 that resulted in 101 cases of illness and 21 fatalities, and more recently in Canada (originating in North York, Ontario) in August 2008, resulting in 57 confirmed cases (mostly in Ontario) and 22 confirmed deaths^(2,7).

HOST RANGE: *L. monocytogenes* has been isolated from many organisms, including humans and other mammals, fish, crustaceans, and insects^(4,10).

INFECTIOUS DOSE: The approximate infective dose of *L. monocytogenes* is estimated to be 10 to 100 million colony forming units (CFU) in healthy hosts, and only 0.1 to 10 million CFU in individuals at high risk of infection⁽¹¹⁾.

MODE OF TRANSMISSION: The predominant mode of *L. monocytogenes* transmission is by ingestion of contaminated food^(1,5,10,11). *L. monocytogenes* can also be transmitted transplacentally from mother to child during pregnancy and via the birth canal during birth^(3,9,10,12). Direct contact with diseased animals may lead to transmission to farmers and veterinarians during the birthing of domestic farm animals⁽¹³⁾. Nosocomial infections and person-to-person transmission (excluding vertical) are recognised but rare⁽¹⁾.

INCUBATION PERIOD: Can vary depending on the mode of transmission and dose received, but typically ranges from 1 to 4 weeks, and can be as high as several months^(4,10). Febrile gastroenteritis as a result of *L. monocytogenes* has a short incubation period, typically 18 to 20 hours^(2,9).

COMMUNICABILITY: *L. monocytogenes* can be transmitted from mother to child during pregnancy and childbirth^(3,9,10,12).

SECTION III - DISSEMINATION

RESERVOIR: Soil, manure, decaying vegetable matter, silage, water, animal feed, fresh and frozen poultry, fresh and processed meats, raw milk, cheese, slaughterhouse waste, and asymptomatic human and animal carriers⁽⁴⁾.

ZOONOSIS: Yes, through consumption of foodstuffs containing infected animal products, manure contaminated vegetables, and by direct contact with animal tissues during birthing and butchering^(1,5,9,10,13).

VECTORS: None.

SECTION IV - STABILITY AND VIABILITY

DRUG SUSCEPTIBILITY: Susceptible to most broad spectrum and gram-positive spectrum antibiotics, except the cephalosporins are active against *L. monocytogenes in vitro*⁽⁸⁾. *In vivo*, the most active are ampicillin and amoxicillin⁽⁸⁾.

SUSCEPTIBILITY TO DISINFECTANTS: At room temperature, *L. monocytogenes* is susceptible to sodium hypochlorite, iodophor compounds, and quaternary ammonium compounds⁽¹⁴⁾. Five to 10-fold higher concentrations of the above compounds are required at 4°C⁽¹⁴⁾.

PHYSICAL INACTIVATION: *L. monocytogenes* can be inactivated by ozone, high pressure (500MPa), and high temperatures (at least 70°C for 2 minutes)^(14, 15).

SURVIVAL OUTSIDE HOST: *L. monocytogenes* is commonly found in nature, particularly in association with soil, is relatively heat resistant, can tolerate cold temperature environments well, and can survive at low pH^(9, 15).

SECTION V – FIRST AID / MEDICAL

SURVEILLANCE: Monitor for symptoms. Listeriosis can be diagnosed in the laboratory by cultivation of the organism, and demonstration of the infectious agent or its products in tissues or body fluids^(1, 10). Several commercially available kits exist for the detection of *L. monocytogenes*. These rapid procedures are based on ELISA and PCR technology; however, none have been validated for use as a diagnostic tool^(2, 4).

FIRST AID/TREATMENT: Treatment for human listeriosis with ampicillin or amoxicillin together with gentamicin is the primary choice of therapy⁽⁸⁾. The recommended course of treatment is ampicillin for 2 to 4 weeks⁽¹⁰⁾. The addition of gentamicin for 2 weeks should be considered for immunocompromised patients⁽¹⁰⁾. An alternative therapy for individuals allergic to β -lactams is intravenous co-trimoxazole⁽¹⁰⁾.

IMMUNIZATION: None currently available.

PROPHYLAXIS: No chemoprophylaxis exists; however, precautions for individuals who are immunocompromised or pregnant women include the avoidance of raw food and vegetables, undercooked meat, soft cheeses, and cheeses prepared from unpasteurised milk⁽¹⁰⁾.

SECTION VI - LABORATORY HAZARDS

LABORATORY-ACQUIRED INFECTIONS: A particularly rare laboratory-acquired infection with some suspected cases, none of which have been confirmed⁽¹⁶⁾.

SOURCES/SPECIMENS: Blood, cerebrospinal fluid, faeces, placenta, skin lesions, pus, amniotic fluid, menstrual blood, lochia, respiratory secretions, meconium, gastric aspirate, animal tissues/specimens, and infected organs such as brain and liver^(2, 4, 10).

PRIMARY HAZARDS: Accidental autoinoculation, exposure to the tissues of experimentally infected animals, and *L. monocytogenes* cultures⁽¹⁷⁾.

SPECIAL HAZARDS: Those at greater risk of infection (pregnant women or immunocompromised individuals) should take extra care when working in a laboratory where *L. monocytogenes* is propagated or handled⁽³⁾.

SECTION VII – EXPOSURE CONTROLS / PERSONAL PROTECTION RISK GROUP

CLASSIFICATION: Risk Group 2⁽¹⁸⁾.

CONTAINMENT REQUIREMENTS: Containment Level 2 facilities, equipment, and operational practices for work involving infectious or potentially infectious material, animals, or cultures.

PROTECTIVE CLOTHING: Lab coat. Gloves when direct skin contact with infected materials or animals is unavoidable⁽¹⁷⁾. Eye protection must be used where there is a known or potential risk of exposure to splashes.

OTHER PRECAUTIONS: All procedures that may produce aerosols, or involve high concentrations or large volumes should be conducted in a biological safety cabinet (BSC)⁽¹⁷⁾. The use of needles, syringes, and other sharp objects should be strictly limited. Additional precautions should be considered with work involving animals or large scale activities.

SECTION VIII – HANDLING AND STORAGE

SPILLS: Allow aerosols to settle and, wearing protective clothing, gently cover spill with paper towels and apply an appropriate disinfectant, starting at the perimeter and working towards the center. Allow sufficient contact time before clean up⁽¹⁷⁾.

DISPOSAL: Decontaminate all wastes that contain or have come in contact with the infectious organism before disposing by autoclave, chemical disinfection, gamma irradiation, or incineration⁽¹⁷⁾.

STORAGE: The infectious agent should be stored in leak-proof containers appropriately labeled⁽¹⁷⁾.

SECTION IX - REGULATORY AND OTHER INFORMATION - UPDATED: December 2011

PREPARED BY: Pathogen Regulation Directorate, Public Health Agency of Canada.

Although the information, opinions and recommendations contained in this Pathogen Safety Data Sheet are compiled from sources believed to be reliable, we accept no responsibility for the accuracy, sufficiency, or reliability or for any loss or injury resulting from the use of the information. Newly discovered hazards are frequent and this information may not be completely up to date.

Copyright © Public Health Agency of Canada, 2011 Canada

REFERENCES:

1. Low, J. C., & Donachie, W. (1997). A review of *Listeria monocytogenes* and listeriosis. *Veterinary Journal*, 153(1), 9-29.
2. Donnelly, C. W. (2001). *Listeria monocytogenes*: A continuing challenge. *Nutrition Reviews*, 59(6), 183-194.
3. Acha, P. N., & Szyfres, B. (2003). Listeriosis. *Zoonoses and Communicable Diseases Common to Man and Animals* (3rd ed., pp. 168-179). Washington D.C.: Pan American Health Organization.
4. Bille, J., Rocourt, J., & Swaminathan, B. (2003). *Listeria* and *Erysipelothrix*. In P. R. Murray, E. J. Baron, J. H. Tenover, & R. M. Tenover (Eds.), *Manual of Clinical Microbiology* (8th ed., pp. 461-471). Washington, D.C.: ASM Press.
5. Gahan, C. G. M., & Hill, C. (2005). Gastrointestinal phase of *Listeria monocytogenes* infection. *Journal of Applied Microbiology*, 98(6), 1345-1353.
6. Doganay, M. (2003). Listeriosis: Clinical presentation. *FEMS Immunology and Medical Microbiology*, 35(3), 173-175.
7. Public Health Agency of Canada. (2008). *Listeria monocytogenes* outbreak. http://www.phac-aspc.gc.ca/alert-alerte/listeria/listeria_2008-eng.php
8. Hof, H. (1991). Therapeutic activities of antibiotics in Listeriosis. *Infection*, 19(SUPPL. 4), S229-S233.
9. Roberts, A. J., & Wiedmann, M. (2003). Pathogen, host and environmental factors contributing to the pathogenesis of listeriosis. *Cellular and Molecular Life Sciences*, 60(5), 904-918.
10. Krauss, H., Schiefer, H. G., Weber, A., Slenczka, W., Appel, M., von Graevenitz, A., Enders, B., Zahner, H., & Isenberg, H. D. (2003). Bacterial Zoonoses. *Zoonoses: Infectious Diseases Transmissible from Animals to Humans* (3rd ed., pp. 205-208). Washington, D.C.: ASM Press.
11. Farber, J. M., Ross, W. H., & Harwig, J. (1996). Health risk assessment of *Listeria monocytogenes* in Canada. *International Journal of Food Microbiology*, 30(1-2), 145-156.
12. Mylonakis, E., Paliou, M., Hohmann, E. L., Calderwood, S. B., & Wing, E. J. (2002). Listeriosis during pregnancy: A case series and review of 222 cases. *Medicine*, 81(4), 260-269.
13. Regan, E. J., Harrison, G. A. J., Butler, S., McLauchlin, J., Thomas, M., & Mitchell, S. (2005). Primary cutaneous listeriosis in a veterinarian [2]. *Veterinary Record*, 157(7), 207.
14. Mafu, A. A., Roy, D., Goulet, J., Savoie, L., & Roy, R. (1990). Efficiency of sanitizing agents for destroying *Listeria monocytogenes* on contaminated surfaces. *Journal of Dairy Science*, 73(12), 3428-3432.
15. Gaze, J. E., Brown, G. D., Gaskell, D. E., & Banks, J. G. (1989). Heat resistance of *Listeria monocytogenes* in homogenates of chicken, beef steak and carrot. *Food Microbiology*, 6(4), 251-259.
16. Collins, C. H., & Kennedy, D. A. (1999). Laboratory acquired infections. *Laboratory acquired infections: History, incidence, causes and preventions* (4th ed., pp. 1-37). Woburn, MA: Butterworth-Heinemann.
17. Public Health Agency of Canada. (2004). In Best B., Graham M. L., Leitner R., Ouellette M. and Ugwu K. (Eds.), *Laboratory Biosafety Guidelines* (3rd ed.). Canada: Public Health Agency of Canada.

Lab Notebook Entries

Page #

Date

Student name

Experiment name

A. Purpose of Procedure

This section is very important. This is not a place to write a one-sentence description of the protocol you are going to do *this* moment, but a place to describe how the protocol fits in to the broader purpose of what is to be accomplished and why. Think about what finding caused you do this experiment, what you want to determine, and what is to be done next.

B. Hypothesis and expected results

What is your hypothesis? Describe the protocol you will be using to test this hypothesis. If everything goes as hypothesized, what will happen?

C. Actual Protocol

Describe the protocol as it is *actually* done. What is actually done may or may not be different from the theoretical protocol... just make sure that a note of everything that is different is made. This is important for any future references made back to this notebook entry for "tips" on how to (or *not* to) do something. There may be information that you currently do not think is important that may be important after additional experiments.

D. Results

The data/results that you actually got . . .no matter how exciting or crazy. Numbers and calculations go in this section. Once again, there are many details that seem clear now that you may forget, write them down now.

E. Conclusions

How well do the Experimental Results match up with the Expected Results. The most important part of this section is what is written when the Experimental Results *don't* match up with the Expected Results; it is under these circumstances that thoughts about why there is a discrepancy are critical.

Proper Notebook Keeping

1. Your notebook is the property of the BYU. It should never leave the lab. It should have on the front cover your name, Dr Weber's name, and the lab room and phone number (801) 422-6716 and a statement saying if found please return to Dr Weber 3137 LSB Brigham Young University, (801) 422-6259 as it contains very important research data.
2. Notebooks should be kept in English.
3. Every entry should have a clear date, including year.
4. Always list catalog number and lot number of reagents.
5. Always write stock and final concentration of reagents.
6. Always write down how a reagent is made, and label the reagent with the page reference in your notebook, so that someone who picks up a tube can track what's in it. Also, if one needs to make up fresh reagent it can be repeated reproducibly.
7. Every experiment should have goal or hypothesis information and proper controls where possible positive and negative controls.
8. Always write step-by-step protocol. If you are following a standard protocol reference the page number in your notebook where the protocol is written out, and clearly describe any deviations from the protocol. If you are following a manufacturer's protocol, specify this in your notebook, with manufacturer's document number (if there is one).
9. Someone who picks up your notebook a year from now should be able to easily reproduce what you did without having to ask about it.

I have been instructed on how to keep a lab notebook. This needs to be done in an organized manner that will allow someone else to find the experiments you did and replicate them if needed.

Sign _____ Super _____ Date _____

I have been instructed on how to store data on the lab computer. All data needs to be accessible on the lab computer and not stored on personal laptops or computers.

Sign _____ Super _____ Date _____

I have been instructed on what to do if the CO₂ is low and the alarm goes off (switch tanks, call Dr. Weber if needed).

Sign _____ Super _____ Date _____

I have been instructed on making sure that the -80°C freezer is properly closed.

Sign _____ Super _____ Date _____

I have been instructed what to do in the event of an emergency.

Sign _____ Super _____ Date _____